

# Add Analog Trunks

Last Modified on 06/13/2015 4:37 pm EDT

Connecting analog trunks to the Wave requires the appropriate physical ports. Some analog trunk ports are included on the Wave hardware (2 on the IP 500 and 4 on the IP 2500.) Additional ports can be added with Wave expansion cards (See [Install Expansion Cards](#)).

There are two steps to configuring analog trunks:

1. Configuring the analog trunk groups. See [Configure Trunk Groups](#).
2. Assigning trunk groups to specific trunks and configuring trunk settings. See [Trunk Configuration](#).

Vertical Wave IP Knowledge Base Content