

# Add Digital Trunks

Last Modified on 06/13/2015 4:44 pm EDT

Connecting digital trunks to the Wave requires adding a T-1 (or E-1) card to the system. T-1s offer either T-1 or PRI signaling. Each T-1 circuit will have one connector to the card (cards may have one or two T-1 ports. See [Install Expansion Cards](#)).

There are two steps to configuring digital trunks:

1. Configuring the trunk groups. See [Configure Trunk Groups](#).
2. Assigning trunk groups to specific trunks and configuring trunk settings. See [Trunk Configuration](#).

Vertical Wave IP Knowledge Base Content