

Activate Wave Licenses

Last Modified on 11/03/2015 1:43 pm EST

1. Login to Wave. (see [Login to Wave IP Global Administrator](#)).
2. From here there are two options:
 - If the Wave has internet access and can reach this [address](#) for one-click activation of licenses (see [One-Click Activation](#)).
 - If the Wave cannot access the internet, it is necessary to use off-line activation method (see [Off-Line Activation](#)).

RELATED ARTICLES [template("related")]

Vertical Wave IP Knowledge Base Content