

Set Up Trunks

Last Modified on 11/03/2015 1:44 pm EST

Settin up Wave phone trunks for inbound and outbound calling.
The Wave includes two major types of trunks:

- SIP trunks or Voice Over IP (VOIP) trunks. To configure these see [Add a SIP Trunk \(SCP\)](#).
- TDM trunks which are divided into:
 - Analog trunks- See [Add Analog Trunks](#).
 - Digital trunks- See [Add Digital Trunks](#).

RELATED ARTICLES [template("related")]

Vertical Wave IP Knowledge Base Content