

Speed Dial (Edge IP 9800 Phone)

Last Modified on 09/27/2017 12:06 pm EDT

Speed dial places a call to the assigned extension or phone number.

1. Press the Speed button.
2. Enter the speed-dial number.
3. Press the Call multi-function button.

The Speed button on your phone only works with local phone speed-dials. To use System Speed Dials, your phone administrator must program a System Speed Dial feature button on your phone.