

# Set Global Administrator user Access Permissions

Last Modified on 11/03/2015 2:13 pm EST

Access Permissions control which parts of Global Administrator a user can access. There are three groups that can be assigned permissions: User, Manager, Enterprise. Any given permission can be set to any of the groups. The groups stack in order from User to Manager to Enterprise. When the Manager group is given a specific permission, the Enterprise group also has access to that permission. If a permission is assigned to the User group then both Manager and Enterprise gains access to that permission.

To set permissions:

1. Login to Global Administrator (see [Login to Wave IP Global Administrator](#)).
2. Click on Access Permissions.

## General Administration

 Chassis View	 Password Administration	 Access Permissions
 General Settings	 SNMP Configuration	 SNMP Alarms
 Software Versions	 System Backup/Restore	 Software Upgrade
 Call Detail Report	 RAID-1 Configuration	 Date and Time
 Restart System	 Report Generator	 Software Licenses
 Download	 Import/Export	 Live Image
 MeetMe Conference		

3. The list that appears has two parts.
  - a. The first column lists the Panel Name. Access Permissions control access to different applets on the Wave IP. The Panel Name column lists the name of the applets that each line item provides access to.

Panel Name	Access Permission
Applications Data Service	Enterprise
Appointment Reminder for CSV File	Enterprise
Authorization Codes	Enterprise
Auto Attendant	Enterprise
AutoAttendant and Voice Mail Configuration	Enterprise
CMS Reports	Enterprise
CRQ General Settings	Enterprise
CRQ Pilot Number Configuration	Enterprise
CRQ Queue Configuration	Enterprise
Call Detail Report	Manager
Chassis View	User
Conference Bridges	Enterprise
Date and Time	Enterprise
Diagnostics	Manager
Download	Manager
Fax Manager	Enterprise
First Digit Table	Enterprise
General Settings	Enterprise
Hunt Groups	Enterprise
IP Network Settings	Enterprise
IP Telephony	Enterprise


Restore Apply Done Help

- b. The second column lists the Permission which is the name of the group that has access to the applet.

Panel Name	Access Permission
Applications Data Service	Enterprise
Appointment Reminder for CSV File	Enterprise
Authorization Codes	Enterprise
Auto Attendant	Enterprise
AutoAttendant and Voice Mail Configuration	Enterprise
CMS Reports	Enterprise
CRQ General Settings	Enterprise
CRQ Pilot Number Configuration	Enterprise
CRQ Queue Configuration	Enterprise
Call Detail Report	Manager
Chassis View	User
Conference Bridges	Enterprise
Date and Time	Enterprise
Diagnostics	Manager
Download	Manager
Fax Manager	Enterprise
First Digit Table	Enterprise
General Settings	Enterprise
Hunt Groups	Enterprise
IP Network Settings	Enterprise
IP Telephony	Enterprise

Restore Apply Done Help

4. Choose the applet to assign access permissions and click on the name of the group assigned to it. A drop-down box will appear with the names of all groups. Choose the group that will have access to this applet.



5. Click Apply and then Done to set the permissions.

**RELATED ARTICLES** [template("related")]